

INSTALLATION GUIDE AND TIPS

STEP ONE:

Set T-posts no more than 6ft apart for Economy Safety Barrier Fencing. 8ft apart for Standard Safety Barrier Fencing and 10ft for Diamond Barrier Fencing. T-posts are recommend for solid installation, but other posts such as Landscape Stake or rebar can come in handy for additional supports.

STEP TWO:

Attach the Safety Barrier fence to one T-post by using a zip tie. Pull the Safety barrier fence taut and secure to each post with zip ties. Be sure to secure the post at both the top of the T-post to keep the fence from drooping and also at the bottom of each T-post to keep the Safety Barrier Fence close to the ground. This will help keep trash and animals from entering the work area.



STEP THREE:



Be sure to utilize the “teeth” of the T-post keep the Safety Barrier Fence from sliding down the post. This will help secure the fence and improve the longevity of the fence.

TIPS:



Weaving rebar through the grid of the fence and driving it into the ground between two T-post can help increase the strength of the fence.



if T-posts are not available and landscaping stakes are used staples, in addition to zip ties, can be used to secure the fence to the stake.



If zip ties are not available you can use Presco Barricade tape or Roll Flagging as a way to secure the fence to the posts.